CONNECTING THE BATTERY TO THE INVERTER

GSIKE 6.2kW 48V WiFi + MFUZOP 51.2V 314Ah 16.07kWh

Connecting the MFUZOP 51.2V 314Ah 16.07kWh battery to the GSIKE 6.2kW 48V WiFi inverter



What is included in the system

- **Inverter GSIKE 6.2kW 48V WiFi**
- **Battery MFUZOP 51.2V 314Ah 16.07kWh**

What else you will need

- Battery–inverter power cables 35 mm², M8 lugs
- RS485 communication cable (RJ45), e.g. “Communication cable 1.3 m”
- DC breaker / fuse 200 A
- 50 A breaker, 10 mm² cable to the grid input
- Screwdriver, 13 mm wrench, multimeter

Wiring diagram



minertech.org · MinerTech® trademark · © 2017–2026, all rights reserved
+38 093 293 93 93 · +38 099 054 40 38 · Specialist Pavlo Leonidovych · strooks@gmail.com

Inverter connectors: bottom panel



№	Connector	What it is	What connects where
1	**Grounding**	Case earthing bolt. The inverter must be connected to a permanent earthing system.	Earth wire (PE) of the panel.
2	**RS485 (BMS)**	Lithium battery BMS port (RJ45 connector). Pins: 1 — RS485-B, 2 — RS485-A, 7 — RS485-A, 8 — RS485-B.	Communication cable from the BMS RS485 port (“pin to pin” cable, included). Battery type: item 05.
3	**RS232**	RS232 communication port. The case is labelled “WIFI” and “RS232” next to it.	The manufacturer’s manual does not describe what exactly connects here or how, so we do not cover it here.
4	**AC grid input**	AC INPUT terminals: ⏚, L, N.	Grid or generator via a separate 50 A breaker. 10 mm² cable.
5	**Main output**	MAIN OUT terminals: L, N (OP1). For powerful loads: air conditioners, heaters, motors.	Main load panel. Cut-off by battery voltage: item 31.
6	**Second output**	SECOND OUT terminals: L, N (OP2). For light loads: lighting, computers, fans. Its cut-off is usually lower than the main output’s, so light loads run longer.	Light load panel. Enable: item 43, cut-off: item 29, overload threshold: item 47.
7	**Battery input**	BATTERY terminals: POS + and NEG –.	48 V battery via separate DC protection. 35 mm² cable, torque 2–3 N·m.
8	**PV input**	Solar panel connectors (+ and –), one input.	Solar panels via a separate DC switch. Up to 500 V open-circuit, MPPT 60–500 V, up to 27 A.

minertech.org · MinerTech® trademark · © 2017–2026, all rights reserved
+38 093 293 93 93 · +38 099 054 40 38 · Specialist Pavlo Leonidovych · strooks@gmail.com

The ON/OFF power switch is on the side wall of the case; this model has no CAN port, dry contact or parallel port.

Key values for this pair

56.8 V charge voltage (26)	**54.4 V** float voltage (27)	**48.0 V** cut-off (31)
Li2 BMS protocol (05)	**100 A** max. charge current (02)	**40 A** grid charging (11)

Connection procedure

1. Mount the inverter vertically on a non-combustible wall in a dry place. Leave at least 20 cm of free space above and below for cooling.
2. Make sure everything is switched off: inverter button OFF, battery switch/button OFF, DC breaker off, 230 V grid not connected.
3. Install a **200 A** DC breaker or fuse between the battery and the inverter in the positive (red) wire.
4. Connect the power cables (cross-section at least **35 mm²**, M8 lugs): **red** from the battery "+" to the inverter "+ BAT", **black** from the battery "−" to "− BAT". Check the polarity twice: swapping "+" and "−" is guaranteed to damage the inverter.
5. Tighten the terminal bolts firmly (without stripping the thread) and fit the protective caps. A loose contact heats up and melts the terminals.
6. Connect the battery and the inverter with the **communication cable** (RJ45): **RS485** port on the battery → **BMS / RS485** port on the inverter. Do not plug the cable into the CAN or WiFi port. For protocol settings, see "Battery communication".
7. Switch on the battery (button or switch on the case, if any), then the DC breaker.
8. Switch on the inverter with the ON button. The battery voltage should appear on the display. Enter the settings from the table below.
9. Switch off the inverter and connect the 230 V grid to the **AC IN** terminals (L, N, PE) through a separate 50 A breaker.
10. Connect the load (your socket/distribution board) to the **AC OUT** terminals (L, N, PE). Never mix up AC IN and AC OUT: feeding grid power into the output damages the inverter.
11. If you have solar panels, connect them to the **PV** input last, observing polarity. The open-circuit voltage of the panels (Voc) rises in frosty weather: do not exceed the PV maximum on the inverter label.
12. Switch on the inverter and check: 230 V at the output, the battery charges from the grid (charging icon on the display), the lights stay on when the grid is off.

minertech.org · MinerTech® trademark · © 2017–2026, all rights reserved
+38 093 293 93 93 · +38 099 054 40 38 · Specialist Pavlo Leonidovych · strooks@gmail.com

Battery communication: Pylon protocol (RS485)

This battery has an RS485 port and “talks” to the inverter: the inverter sees the state of charge in percent (SOC) and takes the correct charge voltages and currents from the BMS by itself.

On the battery:

1. The protocol is selected on the battery display: tab **protocol setting,** line **RS485-PCS,** use the ◀ ▶ buttons to choose **Pylon** and press **Set (** manufacturer’s manual, section 5.6). The **Read** button shows what has been saved.
2. The address of a single battery is **1:** DIP switch **ADS No.** 1 ON, No. 2–4 OFF (5 and 6 are not used).
3. The communication cable to the inverter goes into the battery’s **RS485** port. The RS485-1 / RS485-2 ports are only for linking batteries together.

On the inverter:

1. Program **05** (battery type) = **Li2.**
2. Cable from the inverter **BMS / RS485** port to the battery **RS485** port.
3. Switch the inverter off and on. After 10–30 seconds the battery charge should appear on the display in **%.** If only the voltage or a communication error (warning 19) appears instead of percent, check the cable, port and protocol.
4. Once communication is established, the inverter takes the charge (26, 27) and cut-off (31) voltages from the battery. The values in the table below are a fallback if communication is lost.
5. The thresholds for switching to the grid and back (12, 13) are set in percent with BMS communication: recommended **20%** switch to grid, **80%** return to battery.

Inverter settings

Entering the menu: hold the **ENTER** (or **SET**) button for 3 seconds. Use ▲/▼ to select the program number, press ENTER, change the value, press ENTER to save. Exit: **ESC**.

№	Parameter	Value	Why
01	Output source priority	**UTI** (no panels) or **SBU** (with panels)	UTI: we run from the grid and keep the battery full in case of a power cut. SBU: solar first, then battery, then grid.
02	Maximum charging current (total)	**100 A**	Safe for LiFePO4 314Ah. If the inverter does not allow this much, set its maximum.
03	AC input voltage range	**UPS** (from the grid) / **APL** (from a generator)	UPS: fast switchover, computers do not restart. APL: if you run on a generator.
05	Battery type / BMS protocol	**Li2**	Li2 = PYLON US2000 protocol. Li4 in this inverter is its own protocol, not Growatt.
06	Auto restart after overload	**LTE** (enabled)	The inverter resumes operation by itself.

minertech.org · MinerTech® trademark · © 2017–2026, all rights reserved
+38 093 293 93 93 · +38 099 054 40 38 · Specialist Pavlo Leonidovych · strooks@gmail.com

07	Auto restart after overheating	**TTE** (enabled)	The inverter resumes operation by itself.
09	Output frequency	**50 Hz**	Standard for Ukraine and Europe.
11	Maximum grid charging current	**40 A**	Moderate grid charging so as not to overload the wiring and the battery.
12	Back-to-grid voltage (SBU mode)	**50.0 V**	When the battery discharges to this voltage, the load switches to the grid (if available).
13	Back-to-battery voltage (SBU mode)	**54.0 V**	After recharging to this voltage, the inverter runs from the battery again.
16	Charging source priority	**SNU** (solar + grid)	The battery charges from both solar and grid. Without panels, it charges from the grid.
26	Charge voltage (Bulk / CV)	**56.8 V**	Standard for LiFePO4 16S (51.2 V).
27	Float voltage	**54.4 V**	The battery is not overcharged when it stays on the grid for a long time.
31	Main output cut-off (OP1)	**48.0 V**	The inverter switches off its output so as not to drain the battery to zero and trip the BMS.

Program numbers follow this inverter manufacturer's manual. After entering the settings, switch the inverter off and on again.

Which mode to choose

- **Backup during power cuts only (no panels):** 01 = UTI, 16 = SNU. The inverter runs from the grid and the battery is always full; when the power goes out it switches to the battery automatically.
- **You have solar panels and want to save:** 01 = SBU, 16 = SNU (or CSO). Solar power by day, battery at night, the grid only when the battery has dropped to 50.0 V.
- **Running on a generator:** 03 = APL, 11 = 40 A or less, so as not to overload the generator.

minertech.org · MinerTech® trademark · © 2017–2026, all rights reserved
+38 093 293 93 93 · +38 099 054 40 38 · Specialist Pavlo Leonidovych · strooks@gmail.com

How long it runs on battery

Load	Example	Runtime
200 W	fridge + lights	**≈ 65.1 h**
300 W	fridge + lights + TV	**≈ 43.4 h**
500 W	fridge, laptop, pump	**≈ 26.0 h**
1000 W	boiler, kettle briefly, several appliances	**≈ 13.0 h**
2000 W	air conditioner, water heater, electric stove	**≈ 6.5 h**
4000 W	whole house, pump, power tools	**≈ 3.3 h**

Approximate: 90% of battery capacity and inverter efficiency ≈90%. A fridge runs in cycles, so the real runtime is longer.

Check after start-up

- Battery voltage on the display: ≈ 54.4–56.8 V when full, ≈ 50.0 V when discharged.
- Switch off the grid breaker: the load must keep running without interruption.
- After 10–15 min of operation, touch the terminals and cables: they must not be hot. If they heat up, a connection is loose or the cable is too thin.
- A battery below 46.4 V may have gone into BMS protection: charge it from the grid through the inverter.

Safety. Make all connections only with the battery, inverter and grid switched off. Do not short-circuit the battery terminals: the short-circuit current of LiFePO4 is very high. Do not install the inverter in a bathroom, outdoors in the rain or near flammable materials. If in doubt, contact an electrician.

Shutdown and maintenance

- Switch off in reverse order: load → grid → panels → inverter → DC breaker → battery.
- Every 3 months, check that the terminals are tight and the ventilation openings are clean.
- If you do not use the kit for a long time, charge the battery to 50–70% and switch it off.

minertech.org · MinerTech® trademark · © 2017–2026, all rights reserved
+38 093 293 93 93 · +38 099 054 40 38 · Specialist Pavlo Leonidovych · strooks@gmail.com